



JERRY EASELS EBONY/SILVER, EBONY/GOLD or EBONY/EBONY (Specify)
Jerry Easels mount quickly from the side edge of the insert - photos always stay in place. V and H display.
4 x 5, 5 x 7, 8 x 10
5 x 4, 7 x 5 and 10 x 8
available in Ebony/Gold only.
4 x 6 Ebony/Ebony and Ebony/Silver only
8 x 10 Ebony/Silver not available



ALUMNI EASELS
EBONY/GOLD or BLACK/BLACK
Alumni Easels load from the top. Rear pop-panel allows both V and H display.
4 x 5, 4 x 6, 5 x 7, and 8 x 10

V and H Display
V = Vertical
H = Horizontal

MIRAGE EASEL
EBONY
45/54, 46/64, 57/75, 80/108

Empire Easels are side loading. V and H display. 4 x 5, 5 x 7, or 8 x 10

HICKORY EASEL
EBONY w/GOLD
EBONY w/SILVER
EBONY w/EBONY
45/54 46/64, 57/75, 80/108
can be used as vertical or horizontal



BUDGET EASELS

All easels can be used as vertical or horizontal



EVENT EASEL
4 x 6, 5 x 7, 8 x 10 or 8½ x 11



BIG SHOT EASEL
5 x 7 or 8 x 10



GRAY PANEL MOUNT
3½ x 5, 4 x 5, 4 x 6, 5 x 7 or 8 x 10


Corner Detail



BROADWAY DIGITAL EASEL
Color: Gray
Print loads into embossed, die-cut slots. Shows full frame of image. Dual easel accommodates vertical or horizontal prints.
8 x 10, 8½ x 11, 8 x 12, 5 x 7 and 10 x 13

NEW 4X6

Corner Detail



BLACK DIGITAL EASEL
4 x 6, 5 x 7, 8 x 10, 8½ x 11, and 10 x 13



BLACK PANEL MOUNT
3 x 5, 4 x 5, 4 x 6, 5 x 7, 6 x 8 or 8 x 10





MARBLE PANEL MOUNT
3½ x 5, 4 x 5, 4 x 6, 5 x 7, 6 x 8 or 8 x 10

NEW

PALMETTO EASEL

EBONY w/GOLD
EBONY w/SILVER
EBONY w/EBONY
46/64, 57/75, 80/108
can be used as vertical or horizontal



Easel Backs can be used vertical or horizontal